





# Wireless Notebook Keypad and Mouse set

- QUICK START GUIDE
- GUIDE DE DEMARRAGE RAPIDE
- KURZANLEITUNG
- SNELSTARTGIDS
- GUIDA DI RIFERIMENTO RAPIDO
- MANUAL DE INICIO RÁPIDO




English		
<b>Contents</b>		
1. Keypad		5. 4 AAA Batteries
2. Mouse		6. Quick Start Guide
3. Receiver		7. How to Use Guide
4. Case/Bag		
Français		
<b>Contents</b>		
1. Keypad		5. 4 AAA Batteries
2. Mouse		6. Quick Start Guide
3. Receiver		7. How to Use Guide
4. Case/Bag		
Deutsch		
<b>Contents</b>		
1. Keypad		5. 4 AAA Batteries
2. Mouse		6. Quick Start Guide
3. Receiver		7. How to Use Guide
4. Case/Bag		

- English**
- Setup**
- 1. Install Batteries**
    - a. Mouse
    - b. Keypad
  - 2. Plug Dongle into Laptop**
    - a. Plug Dongle into Laptop
    - b. Press Connect Button on Dongle
  - 3. Connect Keypad**
    - a. Turn ON Keypad
    - b. Press Connect Button on Dongle
    - c. Connect Mode
    - d. Press Connect (5sec) Button on Keypad
    - e. Keypad ready
  - 4. Connect Mouse**
    - a. Turn ON Mouse
      - i. press/hold Scroll Wheel
      - ii. press Connect button (Red LED on bottom lights-up)
    - b. Press Connect Button on Dongle
    - c. Connect Mode: LED Blink inside Dongle
    - d. Press Connect (5sec) Button on Mouse
    - e. Mouse ready

- Français**
- Setup**
- 1. Install Batteries**
    - a. Mouse
    - b. Keypad
  - 2. Plug Dongle into Laptop**
    - a. Plug Dongle into Laptop
    - b. Press Connect Button on Dongle
  - 3. Connect Keypad**
    - a. Turn ON Keypad
    - b. Press Connect Button on Dongle
    - c. Connect Mode
    - d. Press Connect (5sec) Button on Keypad
    - e. Keypad ready
  - 4. Connect Mouse**
    - a. Turn ON Mouse
      - i. press/hold Scroll Wheel
      - ii. press Connect button (Red LED on bottom lights-up)
    - b. Press Connect Button on Dongle
    - c. Connect Mode: LED Blink inside Dongle
    - d. Press Connect (5sec) Button on Mouse
    - e. Mouse ready

- Deutsch**
- Setup**
- 1. Install Batteries**
    - a. Mouse
    - b. Keypad
  - 2. Plug Dongle into Laptop**
    - a. Plug Dongle into Laptop
    - b. Press Connect Button on Dongle
  - 3. Connect Keypad**
    - a. Turn ON Keypad
    - b. Press Connect Button on Dongle
    - c. Connect Mode
    - d. Press Connect (5sec) Button on Keypad
    - e. Keypad ready
  - 4. Connect Mouse**
    - a. Turn ON Mouse
      - i. press/hold Scroll Wheel
      - ii. press Connect button (Red LED on bottom lights-up)
    - b. Press Connect Button on Dongle
    - c. Connect Mode: LED Blink inside Dongle
    - d. Press Connect (5sec) Button on Mouse
    - e. Mouse ready


1




4

CASE  
IMAGE  
TO COME

5



2



3



6



7



## Nederlands

### Contents

- |             |                      |
|-------------|----------------------|
| 1. Keypad   | 5. 4 AAA Batteries   |
| 2. Mouse    | 6. Quick Start Guide |
| 3. Receiver | 7. How to Use Guide  |
| 4. Case/Bag |                      |

## Italiano




### Contents

- |             |                      |
|-------------|----------------------|
| 1. Keypad   | 5. 4 AAA Batteries   |
| 2. Mouse    | 6. Quick Start Guide |
| 3. Receiver | 7. How to Use Guide  |
| 4. Case/Bag |                      |

## Español

### Contents

- |             |                      |
|-------------|----------------------|
| 1. Keypad   | 5. 4 AAA Batteries   |
| 2. Mouse    | 6. Quick Start Guide |
| 3. Receiver | 7. How to Use Guide  |
| 4. Case/Bag |                      |



## Nederlands

### Setup

#### 1. Install Batteries

- Mouse
- Keypad

#### 2. Plug Dongle into Laptop

- Plug Dongle into Laptop
- Press Connect Button on Dongle

#### 3. Connect Keypad

- Turn ON Keypad
- Press Connect Button on Dongle
- Connect Mode
- Press Connect (5sec) Button on Keypad
- Keypad ready

#### 4. Connect Mouse

- Turn ON Mouse
  - press/hold Scroll Wheel
  - press Connect button (Red LED on bottom lights-up)
- Press Connect Button on Dongle
- Connect Mode: LED Blink inside Dongle
- Press Connect (5sec) Button on Mouse
- Mouse ready

## Italiano

### Setup

#### 1. Install Batteries

- Mouse
- Keypad

#### 2. Plug Dongle into Laptop

- Plug Dongle into Laptop
- Press Connect Button on Dongle

#### 3. Connect Keypad

- Turn ON Keypad
- Press Connect Button on Dongle
- Connect Mode
- Press Connect (5sec) Button on Keypad
- Keypad ready

#### 4. Connect Mouse

- Turn ON Mouse
  - press/hold Scroll Wheel
  - press Connect button (Red LED on bottom lights-up)
- Press Connect Button on Dongle
- Connect Mode: LED Blink inside Dongle
- Press Connect (5sec) Button on Mouse
- Mouse ready

## Español

### Setup

#### 1. Install Batteries

- Mouse
- Keypad

#### 2. Plug Dongle into Laptop

- Plug Dongle into Laptop
- Press Connect Button on Dongle

#### 3. Connect Keypad

- Turn ON Keypad
- Press Connect Button on Dongle
- Connect Mode
- Press Connect (5sec) Button on Keypad
- Keypad ready

#### 4. Connect Mouse

- Turn ON Mouse
  - press/hold Scroll Wheel
  - press Connect button (Red LED on bottom lights-up)
- Press Connect Button on Dongle
- Connect Mode: LED Blink inside Dongle
- Press Connect (5sec) Button on Mouse
- Mouse ready